
Change the temperature display on the Smart Thermostat to Celsius or Fahrenheit

The Smart Thermostat (ADC-T3000 or ADC-T2000) displays temperature based on the system's account settings set on the Customer Website.

For information about changing the temperature display on the security panel, refer to each panel's [Change the temperature format \(units\)](#) guide.

To remotely change between the Celsius and Fahrenheit temperature display:

Note: This changes the temperature units displayed on the Customer Website, Customer app, and the Smart Thermostat display.

1. Log into the Customer Website.
2. Click **Settings**.
3. Click **Account Management**.
4. Click **System Information**.
5. Using the *Temperature Units* dropdown menu, select either **Celsius** or **Fahrenheit**.
6. Click **Update**. The displayed temperature on the thermostat updates shortly after this is complete.

To locally change between the Celsius and Fahrenheit temperature display:

Note: The temperature display can only be changed locally on the ADC-T3000. To change the temperature display on the ADC-T2000, see the steps above.

1. Press the **–** button on the ADC-T3000.
2. Select **SETTINGS**.
3. Select **USER**.
4. Select **F/C**.
5. Select **F** or **C**.

Additional resources

 Enroll in the following training courses today:



[https://answers.alarm.com/ADC/Partner/Installation_and_Troubleshooting/Thermostats/Alarm.com_Smart_Thermostat_\(ADC-...](https://answers.alarm.com/ADC/Partner/Installation_and_Troubleshooting/Thermostats/Alarm.com_Smart_Thermostat_(ADC-...)

Updated: Mon, 20 Apr 2020 20:02:16 GMT

- [Alarm.com Smart Thermostat Installation 201](#)
- [Product Training – Smart Thermostat Installation](#)
- [Smart Thermostat Features & Benefits 101](#)

For more information on accessing Academy Training, see [How can I access Academy Training?](#).

